



Modify #103 Button Front Blouse for a full abdomen or maternity wear.


It's easy to inject fullness to the front of a basic blouse. Follow these steps that show you how to transfer the excess fabric from your bust dart to the tummy where you need it.



2. Cut along both lines leaving a tiny hinge of paper to pivot with at Bust Point.



3. Close Bust Dart. The fullness will be transferred to the tummy area.



4. Add a bit more length to the front. An inch is a good amount. Taper to nothing at the side seam.